

User Manual

M2-600/700/800/900/1000W/G/WG
Single-Phase Microinverter

Version 1.0



Please scan QR code to
download MOCOWINI
APP and get more
technical support.



© 2024 Hangzhou Hailiang New Energy Technology Co.Ltd. All rights reserved.

This document cannot be copied fully or partially, transferred, or distributed in any form without the prior written permission of Hangzhou Hailiang New Energy Technology Co., Ltd.

TRADEMARK

MOCOWINI and other MOCOWINI trademarks are the trademarks or registered trademarks of MOCOWINI. All other trademarks mentioned herein are the properties of their respective owners.

Warning

The content of this manual may be continually reviewed and amended, due to product enhancements or any other reasons. Unless otherwise stated, this manual is not a substitute for the safety instructions or labelling on the equipment. All descriptions herein are for reference only

Other information

Product information is subject to change without notice. The user manual will be updated regularly, please visit the official website of Hangzhou Massive New Energy: www.mocowini.com to obtain the latest

CONTENTS

I About This Manual	4
1.1. Target Group	4
1.2. Validity	4
1.3. Symbol Definition	4
II Safety Instructions	5
2.1. Safety Requests	5
2.2. PV Side Safety Requests	6
2.3. AC Side Safety Requests	6
2.4. Microinverter Safety Requests	6
2.5. Personal Safety Requests	8
2.6. Radio Interference Statement	8
III Product Introduction	9
3.1. Product Overview	9
3.2. Product Function Introduction	9
3.3. Appearance	11
3.3.1 Terminals Introduction	11
3.3.2 Dimension(mm)	12
3.3.3 Label Description	12
3.4. Type of Grid Connection	13
3.5. Circuit Diagram	13
IV Product Receiving and Storage	14
4.1. Receiving and check	14
4.2. List of main annexes	14
4.3. Storage	14
V Installation	15
5.1. Installation environmental requirements	15
5.2. Mounting bracket requirements	15
5.3. Installation Tools Requirements	16
5.4. Microinverter Installation	16
VI Electrical Connection	18
6.1. Safety Precautions	18
6.2. PV Cable Connection	19
6.3. AC Cable Connection	20
6.3.1 Schematic diagram of single microinverter connection	20
6.3.2 Schematic diagram of two microinverter connection	21
6.3.3 AC Cable unlock	22
6.3.4 Cable accessories and usage	22

6.4. PV Cable Connection	22
VII Equipment Debugging	23
7.1. Check before power on	23
7.2. Power on Procedure	23
VIII System Debugging	24
8.1. System indicator description	24
8.2. APP Set inverter parameters	24
IX System Maintenance and Troubleshooting	25
9.1. Troubleshooting	25
9.2. Routine Maintenance	31
9.3. Microinverter Shutdown	31
9.4. Microinverter Disassembly	32
9.5. Microinverter Disposal	32
X Technical Parameters	33
Appendix	34
Installation drawing template	

I About This Manual

This manual contains product information, installation, electrical connections, tuning and testing, troubleshooting and maintenance. Please read this manual carefully before installing and operating the product. All installers and users should understand product features, functions and safety precautions. This manual is subject to change without notice. Please refer to MOCOWINI official website at www.mocowini.com for more product details and the latest documentation.

1.1.Target Group

This manual is only for qualified technicians with PV system installation. The technician should be familiar with the product, local standards and the electrical system. The instructions contained in this manual should be strictly followed during installation, operation and maintenance.

1.2.Validity

Product Model	Nominal Output Power	Nominal Output Voltage
M2-600G, M2-600W, M2-600WG,	600W	220/230/240 V
M2-700G, M2-700W, M2-700WG,	700W	
M2-800G, M2-800W, M2-800WG,	800W	
M2-900G, M2-900W, M2-900WG,	900W	
M2-1000G, M2-1000W, M2-1000WG,	1000W	

1.3.Symbol Definition

Symbol	Description
 DANGER	This indicates a hazardous situation that can result in deadly electric.
 WARNING	This indicates that directions must be strictly followed to avoid safety hazards including equipment damage and personal injury.
 CAUTION	This indicates that the act is forbidden. You should stop, use caution and fully understand the operations explained before proceeding.
	This symbol indicates highlighted information or additional text. Or some tips and tricks for solving product-related problems.

II Safety Instructions

2.1. Safety Requests

WARNING

The microinverter is designed and tested in strict accordance with relevant safety standards. The installer must read and follow all safety instructions and cautions before any operation. The microinverter is electrical equipment and incorrect operation may result in personal injury or property damage.

- a) Only qualified professionals who have read this manual should install and replace MOCOWINI microinverter.
- b) The electrical installation of MOCOWINI microinverter must comply with local electrical regulations
- c) Check the product before installation to make sure there is no damage caused during transportation.
 - If damaged, the insulation performance or safe distance range of the micro inverter may be affected.
 - Choose installation location carefully and adhere to specified installation requirements.
 - Unauthorized removal of necessary protections, improper use, incorrect installation and operation may cause damage to the equipment or incur serious safety and shock hazards
- d) When using the microinverter, make sure that the parameters of the operating environment are within the range shown in the technical specifications.
- e) Please read all instructions and warning signs within this manual and on the PV modules, before installing and using the MOCOWINI microinverter.
- f) Before disconnecting the microinverter from the PV module, the AC side power grid must be disconnected first. To avoid scalding, make sure that the surface temperature of the microinverter is safe, do not directly touch the shell of the microinverter
- g) Do not attempt to repair the microinverter. If the microinverter is suspected to be faulty, please contact MOCOWINI Customer Service to start troubleshooting and obtain a RMA (Return Merchandise Authorization) code to start the replacement process if needed. Private damaging or opening the microinverter will void the warranty.
- h) In case of non-standard installation or abnormal equipment, please consult your local dealer.

2.2.PV Side Safety Requests

WARNING

- a) Ensure that component shells and mounting systems are reliably grounded.
- b) Ensure that the positive and negative connectors of the PV modules are not short-circuited to ground. Otherwise, it will cause serious damage to the microinverter.
- c) Ensure that the DC cables are firmly, securely and correctly connected.
- d) Ensure that the PV module voltage is within the voltage range allowed by the microinverter. Over-specification ranges are not permitted.
- e) Do not connect batteries or other sources of power supply with the input side of microinverter.

2.3.AC Side Safety Requests

WARNING

- a) Ensure that the voltage and frequency of the microinverter meet the requirements for grid connection.
- b) It is recommended that additional protective devices such as AC breakers or fuses be installed on the AC side. The protective device should be sized at least 1.25 times the maximum AC output current.
- c) Ensure that all grounding wires are securely connected. When there are multiple microinverters, ensure that all grounding points on the body are equipotential connections.

2.4.Microinverter Safety Requests

DANGER

- a) All labels and warning signs should be clearly visible once installed. Do not scribble, damage or cover any labels on the equipment.
- The warning label on the micro inverter is as follows.

Symbol	Description
	<p>Caution</p> <p>Do not come within 8 inches (20 cm) of the microinverter when it is in operation.</p>
	<p>Delayed discharging</p> <p>After power-off, wait for 5 minutes to return to normal after the components are fully discharged.</p>
	<p>Danger of high voltage</p> <p>The high voltage generated by microinverter can endanger life.</p>
	<p>Beware of hot surface</p> <p>The microinverter will generate heat during operation. Do not touch the metal surface.</p>
	<p>CQC Mark</p> <p>This micro inverter complies with China CQC standards.</p>
	<p>Read manual first</p> <p>Read the user manual carefully before installation, operation and maintenance.</p>
	Earthing point



DANGER

- a) Damage to equipment that may result from unauthorized dismantling or modification is not covered by the warranty.
- b) Do not touch the operating equipment to avoid injury due to high temperature.
- c) Please install the equipment out of the reach of children.
- d) Please install the equipment in the location away from electromagnetic interference.

2.5. Personal Safety Requests

Only qualified professional technicians can install and operate the microinverter. Professional technicians must:

- a) be professionally trained.
- b) read this manual thoroughly, and master the safety matters related to operation.
- c) be familiar with relevant safety regulations for electrical systems.

2.6. Radio Interference Statement

This microinverter complies with the requirements of EMC (EMC regulations are designed to provide reasonable protection against harmful interference in a residential installation). This equipment can radiate radio frequency energy, if not installed or used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by the following measures:

- a) Relocate the receiving antenna away from other devices.
- b) Contact local dealer or an experienced radio/TV technician for help.


*Note: Any unauthorized changes may result in a loss of the user's right to use the device.

III Product Introduction

3.1. Product Overview

The MOCOWINI microinverter is a miniature single-phase grid-tied photovoltaic inverter. The microinverter converts the DC power generated by the PV modules into AC power for use, and can also be provided to the grid. MOCOWINI microinverter can maximize the energy output of the whole solar array when it encounters unsatisfactory conditions such as shadow occlusion, dirt accumulation, illumination deviation or mismatch in practical application, to maximize the power generation performance of photovoltaic system.

The diagram of microinverter is as follows:



3.2. Product Function Introduction

The N2 series of MOCOWINI microinverters have an output of up to 1600W to adapt to balcony/roof and other household photovoltaic scenarios. Product innovation and rigorous design maximize power generation.

The product is encapsulated with all silicone gel to reduce stress on electronic components, promote heat dissipation, enhance water resistance, and ensure product reliability through rigorous testing methods (including accelerated life test). Through the APP or portal website, it is possible to check the running status of the system anytime, which is convenient for operation and maintenance.


M2 Series Highlights:

- a) Single unit connects to 2 pcs of 500W high power modules ($V_{oc} < 60Vdc$) or 4 pcs of 400W modules
- b) Maximum output power up to 800 W
- c) IP67 High protection level
- d) WiFi/Bluetooth communication for stable communication
- e) Safety protection relay integrated, enabling grid isolation protection
- f) Module-level rapid shutdown for safer use
- g) Suitable for most crystalline silicon modules and thin film modules
- h) 2 input channels with independent MPPT for module-level monitoring function
- i) Maximum 125% DC oversizing

M2 Series Communication Method


- a) Multiple devices communicate through Bluetooth MASH, and one device links to the cloud server through WiFi to monitor the operating status of the microinverter in real time.
- b) Bluetooth: Complies with the Bluetooth 5.0 standard.
- c) WiFi: support 2.4G frequency band. Set the router to 2.4G mode.
- d) The maximum input length supported by the router wireless signal name is 32 bytes.
- e) In order to ensure the communication quality, it is recommended to choose a router with high wireless gain or more antennas, and wireless repeater or outdoor router if needed.

When multiple microinverters work in parallel, the device with a strong signal can be designated as the communication root node through the MOCOWINI APP. Please refer to the MOCOWINI APP instruction for details.




3.3. Appearance

3.3.1. Terminals Introduction




No.	Component or Position	Description
1	Handle	For handling during transport or installation
2	Ground Hole	Connect with the ground point of earth wire
3	Antenna	Wireless communication, support 2.4G WiFi and Bluetooth, Sub-1G is optional
4	LOGO	
5	Label Position	Labelling position
6	PV Connector	Connect with PV modules
7	LED Indicator	Display the operating status of the device
8	AC Connector	Connect with the grid
9	Mounting Hole	Install microinverter

3. 3. 2. Dimension (mm)




3.3.3. Label Description




3.4. Type of Grid Connection

The product supports the following four types of grid connection



3.5. Circuit Diagram



IV Product Receiving and Storage

4.1.Receiving and check

- a)Check the packaging box for damage, such as holes, cracks, deformation and other signs of packaging damage. If damage is found, please do not open the package and contact the supplier as soon as possible.
- b)Check the microinverter model. If the microinverter model is not what you requested, please do not unpack the package and contact the supplier.
- c)Check whether the accessory model is correct and complete, as well as whether the appearance is intact. If damage is found, please contact the supplier as soon as possible.

4.2.List of main annexes

No,	Name	Quantity	Remark
1	Microinverter	1	standard equip
2	Socket Head Cap Screw M8*20	2	optional
3	Plain washer	2	optional
4	Spring washer	2	optional
5	Nut	2	optional
6	PV spanner	1	optional
7	AC bus adapter	1	optional
8	AC bus T-head	1	optional
9	AC Bus T-Head Removal Tool	1	optional
10	AC bus protection cover	1	optional
11	DC Connector Dust Plugs - Male	2	optional
12	DC Connector Dust Plugs - Female	2	optional

4.3.Storage


If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements.

- a) Do not open the outer packaging.
- b) Store the equipment in a clean place. Ensure that the temperature and humidity are appropriate and that there is no moisture condensation.
- c) Stacking height and orientation of the microinverter should follow the instructions on the box.
- d) Microinverters must be stacked carefully to prevent falling.
- e) If the microinverter has been stored for a long time, it should be inspected by a professional before being put into use.

V Installation

5.1. Installation environmental requirements

- a) Do not install the microinverter near flammable, explosive or corrosive substances.
- b) Install the microinverter on a solid surface sufficient to withstand its weight.
- c) Please install the equipment in a well-ventilated place to ensure good heat dissipation. In addition, the installation space should be large enough for easy operation.
- d) Install the equipment in a cool place, away from direct sunlight, rain, snow, and ultraviolet radiation.
- e) Do not install the equipment in a place that is easy to touch, especially where children can reach it. It's high temperature while the equipment operating, do not touch the surface to avoid scalding.
- f) Please install the equipment in a place where it is easy for O & M and electrical connection, and where it is easy to check the height of the indicators and labels.
- g) Please install the equipment in the location away from electromagnetic interference.



5.2. Mounting bracket requirements

- a) Mount the microinverter on a PV-specific bracket. Ensure that the PV mount is strong enough to support the weight of the microinverter.
- b) Ensure the mechanical compatibility of the microinverter connector with the connector of the PV module to which it is connected.

5.3. Installation Tools Requirements

a) The following tools are required to install the microinverter, and other auxiliary tools may be used on site.




5.4. Microinverter Installation

Please carry the microinverter to the site before installation. Follow the instructions below to avoid personal injury or equipment damage.







WARNING

- a) Please consider the weight of the equipment before handling it. And arrange for sufficient personnel to operate the equipment to avoid personal injury.
- b) Wear safety gloves to avoid personal injury.
- c) While handling equipment, please keep balance to avoid falling.
- d) Do not bump or hit the antenna, otherwise it may be damaged.
- e) It is forbidden to pick up the cable directly by hand, and it is recommended to lift the handle of the microinverter to carry and install it.
- f) A clearance of at least 20mm should be left around the microinverter enclosure to ensure ventilation and heat dissipation.



WARNING

- g) Before installation, please position the installation location of the microinverters and PV modules, and it is recommended to mark the relevant position on the rail.
- h) Fix the microinverter on the mounting rail. Prepare aluminium clips to fix the mounting screws during installation, the holes on the rail are not suitable for microinverter installation.
- i) Wear goggles and dust masks when drilling holes, to prevent dust inhalation or touch the eyes.
- j) Prepare suitable M8 screws and fix them to the bracket in a suitable position according to the size of the rail and the thickness of the microinverter handle (6.5mm).



VI Electrical Connection

6.1. Safety Precautions




WARNING

- a) Before making any electrical connection, please disconnect the PV module connectors and the AC output switch of the microinverters, as well as the power supply to the microinverters.
- b) Electrical connection should comply with local laws and regulations, including operation, cables and component specifications.
- c) Avoid excessive tension on the cable, which may result in a poor connection. It is necessary to reserve a certain length of cable in front of the microinverter.

Precautions:

- a) Personal protective equipments such as safety shoes, safety gloves, insulated gloves must be used during electrical connection.
- b) All electrical connections shall be made by qualified professionals.
- c) The cable colors in the document are for reference only. Cable specifications shall comply with local requirements, laws and regulations.
- d) Microinverters must be licensed by the power sector of the country/region where they are located.
- e) Positioning before connecting to the grid.
- f) Before electrical connections, please prepare the cables according to the installation plan.
- g) After the inverter is installed, remove the removable serial number label from the microinverter, paste it on a paper, create an installation plan, and then register the power station by scanning the serial number through the APP.
- h) Monitor the operating status of the microinverter.

Schematic diagram of the system network of 2 microinverters connected in parallel




6.2.PV Cable Connection



WARNING

- a) When connecting multiple microinverters, ensure that all grounding points are equipotential.
- b) In order to improve the corrosion resistance of the grounding terminal, it is recommended to coat the grounding terminal with silica gel or paint after the PE cable is installed.
- c) PE cable is prepared by customer. Recommended specification: 6mm²(AWG). M4 grounding OT terminal is prepared by customer.




6.3.AC Cable Connection




WARNING

- a) Microinverters are only allowed to be connected to the grid.
- b) An AC circuit breaker should be installed on the AC side to ensure that the inverter can be safely disconnected from the grid under abnormal conditions. Please select the appropriate AC circuit breaker according to local laws and regulations.
- c) Pay attention to the "L", "N" and "PE" marks on the AC connectors. Connect the wires to the corresponding terminals. If it is not properly wired, the microinverter may be damaged.
- d) Make sure the power cord core is fully plugged into the AC connector. The cable core shall not be exposed.
- e) Make sure that the cables are securely connected. Otherwise, the connectors may overheat and damage the microinverter while operating.
- f) When the AC connector is not used, seal the AC connector with a sealing plug. Otherwise, it will affect the protection level.
- g) AC cables can be purchased from the manufacturer or prepared by the user.
Recommended specification: 4mm² or 10AWG, 12AWG.
- h) Direct plug-in type (terminal connector is optional) for single microinverter.


6.3.1.Schematic diagram of single microinverter connection:




6.3.2.Schematic diagram of two microinverter connection:




1.Take one main thread body of connector.




2.Using the main unlock tool, open the lid.




3.According to the requirements of the system, intercept a certain length of cable and strip both ends of the cable, with the outer core stripped of 40 ± 5 mm and the inner core stripped of 8 ± 1 mm.




5.Repeat step 4,connect the other end of the cable,lock the two nuts, torque 4.0 ± 0.5 N·m




4.Before wiring, use 2# phillips screwdriver to retighten the screw to the top end baffle, then the cable passes through the body shell, and insert the inner core wire into the inside of the terminal according to L,PE,N mark on the box body, lock the screw,screw torque 0.4 ± 0.1 N·m.




6.Press follow the guiding arrow on the box body and the box cover, lifted the box cover,-clamping in place will have a clear sound.




8.Install the branch line onto the main line.During installation,align the guiding arrows of the main line and the branch line and insert them into the mainline. There will be a clear sound when the branch line is clamped in place.



7.Take a suitable number of connectors for backup use as required by system.




9.Tight with tie belt or steel wire belt, etc., the connector will be tied tightly in the appropriate position of the bracket,to ensure the solid and reliable.




10. Connect the micro inverter to the T-connector.

6.3.3.AC Cable unlock

Main line unlock



Use the unlocking tool to align the card slot on the opposite side of the box body, press hard, the box cover will spring open for a certain distance automatically, and then separate the box cover by hand





Use the unlocking tool to align the clasp slot (the unlocking tool incline is downward), and push hard inward. The clasp will spring open for a certain distance, and then separate the branch lines by hand

6.3.4.Cable accessories and usage



Main Cable hard protective cover

When installing the system, when a main line is temporarily not use, use this protective cover, align the clasp and buckle it, and there will be a clear sound when the clasp is clamped in place



Main Cable end guard cover

The system end seal protection use this protective cover. After insertion, lock the nut



6.4.PV Cable Connection



DANGER

a) Before connecting the PV module to the microinverter, please confirm the following information. Otherwise, the microinverter may be permanently damaged or even cause a fire incidents, resulting in personal and property damage.

- Ensure that the maximum short-circuit current and maximum input voltage of per MPPT are consistent with the microinverter.
- Ensure that the negative connector of the PV module is connected to the positive connector of the microinverter, and the positive connector of the PV module is connected to the negative of the microinverter.

b) Do not plug and unplug the connector while the microinverter is operating.



WARNING

c) Use the MC4 PV connector to connect the PV cable. If other connectors are used, the manufacturer is not liable for damage.

d) Before connecting the PV module to the microinverter, ensure that the minimum isolation resistance to ground meets the requirements.


e) Connect the connectors of the two PV modules in parallel to the connector of the microinverter.

f) DC cables can be purchased from the manufacturer or prepared by the user. It should meet over current requirements.

g) When PV connectors are not in use, seal the PV connectors with a waterproof cover. Otherwise, it will affect the protection level.

VII Equipment Debugging

7.1. Check before power on



- a) The microinverter is firmly installed in a clean, ventilated, and easy to operate place.
- b) PE cable, PV DC input and AC output cables should be connected correctly and reliably.
- c) Ties are intact and arranged neatly and evenly.
- d) Unused ports and terminals must be sealed.
- e) The contact voltage and frequency meet the grid-tied requirements of the microinverter.

7.2. Power on Procedure

- a) Step 1: Connect the PV connectors of the microinverter and the PV module.
- b) Step 2: Close the AC circuit breaker between the microinverter and the grid.

VIII System Debugging

8.1 System indicator description

Indicator color status	Description
Flashing Yellow once every second 	System self-checking
Flashing Green once every second 	The system is generating power normally
Flashing Yellow twice every second 	The system is running and an alarm is displayed
Flashing Red twice every second 	System failure
• Note: The microinverter is powered by DC side. If the LED light is not on, please check the DC side connection. If the connection and input voltage are normal, but the LED light is still not on, please contact your local dealer	

8.2 APP Set inverter parameters

Mocowini APP is a mobile application dedicated to Hangzhou's Hailiang new energy products. It connects to the Internet server through Bluetooth and WiFi. The commonly used functions are as follows:

1. Set networking parameters and communication parameters.
2. User information management.
3. Check running data, alarm messages, software version, etc.
4. Equipment maintenance.

Visit www.mocowini.com or scan the installer APP and read the user manual.



Mocowini APP



APP User Manual

IX System Maintenance and Troubleshooting

9.1.Troubleshooting

Fault code	Fault cause	Suggested measure
102	No device detected	<p>1. Place the device close to the router or communication port.</p> <p>2. Check whether the network configuration is complete and correct.</p>
103	Overtemperature fault	<p>1. Check the ventilation and ambient temperature of the installation point.</p> <p>2. If the ventilation is poor or the ambient temperature is high, improve the ventilation or heat dissipation.</p> <p>3. If the heat dissipation and ambient temperature are normal, contact professional engineers, dealers, and after-sales service for technical support.</p>
104	Hardware failure	For technical support, contact your dealer or after-sales service.
105	Hardware failure	<p>1. Check whether the resistance between the photovoltaic array and the protection ground (PE) exceeds 50 kΩ. If the value does not exceed the threshold, check whether a short circuit exists and rectify the fault.</p> <p>2. Check whether the protection ground cable (PE cable) is correctly connected.</p> <p>3. If the insulation resistance is lower than the default value in an environment with high humidity, such as rainy days, reset the insulation monitoring system (ISO). In this case, you may need to temporarily disconnect the power supply and wait for the environment to dry before measuring.</p> <p>4. If the preceding checks are normal, contact professional personnel or the dealer or after-sales service for technical support.</p>
106	Hardware failure	

Fault code	Fault cause	Suggested measure
107	Power grid fault	<p>1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable.</p> <p>2. If the problem occurs occasionally, it may be a temporary anomaly in the power grid. When the power grid is detected to return to normal, the microinverter will automatically resume operation.</p> <p>3. If the problem occurs frequently, check whether the power grid frequency/voltage is within the allowable range.</p> <p>4. If the preceding checks are normal, contact professional personnel or contact the dealer or after-sales service for technical support.</p>
201	The input voltage of the PV1/2 port exceeds DC-60V	<p>1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable.</p> <p>2. Ensure that the short circuit current of the photovoltaic module does not exceed the maximum short circuit current of the microinverter to ensure compliance with the specifications of the microinverter.</p> <p>3. Check whether the photovoltaic module is abnormal.</p> <p>4. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.</p>
202	The input voltage of port PV1/2 is lower than that of DC-16V	<p>1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable.</p> <p>2. Ensure that the short circuit current of the photovoltaic module does not exceed the maximum short circuit current of the microinverter to ensure compliance with the specifications of the microinverter.</p> <p>3. Check whether the photovoltaic module is abnormal.</p> <p>4. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.</p>

Fault code	Fault cause	Suggested measure
203	The input voltage of the PV port is lower than DC-16V	<p>1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable.</p> <p>2. Ensure that the PV modules connected to the two microinverters are of the same model and specifications.</p> <p>3. Check whether the photovoltaic module is abnormal and ensure that it is not damaged, shielded, or dirty .</p> <p>4. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.</p>
204	Hardware failure	<p>1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable.</p> <p>2. Ensure that the short circuit current of the photovoltaic module does not exceed the maximum short circuit current of the microinverter to ensure compliance with the specifications of the microinverter.</p> <p>3. Check whether the photovoltaic module is abnormal.</p> <p>4. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.</p>
205	Hardware failure	<p>1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable.</p> <p>2. Ensure that the short circuit current of the photovoltaic module does not exceed the maximum short circuit current of the microinverter to ensure compliance with the specifications of the microinverter.</p> <p>3. Check whether the photovoltaic module is abnormal.</p> <p>4. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.</p>

Fault code	Fault cause	Suggested measure
206	Hardware failure	<ol style="list-style-type: none"> 1. Check the connection between the photovoltaic module and the microinverter to ensure that the connection is correct and reliable. 2. Ensure that the short circuit current of the photovoltaic module does not exceed the maximum short circuit current of the microinverter to ensure compliance with the specifications of the microinverter. 3. Check whether the photovoltaic module is abnormal. 4. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.
207	Software fault	<ol style="list-style-type: none"> 1. Turn off the AC output switch and DC input switch, and reconnect them 5 minutes later. 2. If the problem persists after the preceding operations, contact professional personnel or the dealer or after-sales service for technical support.
208	Hardware failure	
209	Hardware failure	<ol style="list-style-type: none"> 1. Check the configuration of the PV array to ensure that the power of the PV module matches that of the microinverter and that cables are correctly connected to the PV array to avoid input exceptions caused by improper configuration.
210	Hardware failure	<ol style="list-style-type: none"> 2. Turn off the AC output switch and DC input switch, and reconnect them 5 minutes later to reset the microinverter and the PV system. 3. If the problem persists after the preceding operations, contact professional personnel or the dealer or after-sales service for technical support.

Fault code	Fault cause	Suggested measure
301	Software fault	<p>1. Check the configuration of the PV array to ensure that the power of the PV module matches that of the microinverter and that cables are correctly connected to the PV array to avoid input exceptions caused by improper configuration.</p>
302	Hardware failure	<p>2. Turn off the AC output switch and DC input switch, and reconnect them 5 minutes later to reset the microinverter and the PV system.</p>
303	Hardware failure	<p>3. If the problem persists after the preceding operations, contact professional personnel or the dealer or after-sales service for technical support.</p>
304	10min The overvoltage is faulty	
305	Overvoltage fault	
306	Overvoltage fault	
307	Undervoltage fault	
308	Undervoltage fault	
309	Overfrequency fault	
310	Overfrequency fault	
311	Underfrequency fault	
312	Underfrequency fault	
313	Software fault	
314	Software fault	<p>1. If the problem is caused by an external fault, such as abnormal power grid or abnormal frequency, the microinverter usually automatically returns to normal operation after these problems are eliminated.</p> <p>2. If the problem occurs frequently and the photovoltaic power station cannot work normally, please contact the distributor or after-sales service department in time for further equipment inspection and troubleshooting.</p>

Fault code	Fault cause	Suggested measure
315	Hardware failure	<p>1. Check the configuration of the PV module to ensure that the power of each component matches and cables are correctly connected to avoid input exceptions caused by improper configuration.</p> <p>2. Turn off the AC output switch and DC input switch, and reconnect them 5 minutes later to reset the microinverter and the PV system.</p> <p>3. If the problem persists, please contact the dealer or after-sales service department in time.</p>
316	Island protection	<p>1. If the problem occurs occasionally, the power grid may be temporarily abnormal. When the power grid is detected to return to normal, the microinverter will automatically resume operation.</p> <p>2. If the fault occurs frequently, check whether the power grid frequency/voltage is within the allowable range.</p> <p>3. If all the above check results are normal, consult professional personnel or contact the dealer or after-sales service for technical support.</p>

9.2. Routine Maintenance

Disconnect the microinverter from the power grid and photovoltaic modules before operation and maintenance. Otherwise, it may damage the microinverter or cause an electric shock.

Maintenance Items	Maintenance Method	Maintenance cycle
System cleaning	Check the appearance of the product for foreign objects or dust.	Every 6 to 12 months
Electrical connection check	Check whether cables are securely connected. Check whether the cable is broken and the copper core is exposed.	Every 6 to 12 months
Seal check	Check that all terminals and ports are properly sealed. If the cable holes are not sealed or are too large, reseal them.	Once every 12 months

9.3. Microinverter Shutdown



DANGER

- a) Please power down the microinverter before operation and maintenance. Otherwise, it may damage the microinverter or cause electric shock.
- b) Delayed discharge. Please wait until the parts is powered down and then discharge it.

Operation Procedure

Step 1: Turn off the AC switch between the microinverter and the power grid.

Step 2: Disconnect the PV connector between the microinverter and the PV module.

9.4. Microinverter Disassembly



DANGER

- a) Ensure that the micro inverter is powered off.
- b) Wear personal protective equipment before operation.

Operation procedure

- Step 1 Remove all cables, including DC cables, AC cables, and PE cables.
- Step 2: Remove the micro inverter from the photovoltaic bracket and place it in the original packaging or equivalent wrapping paper box.
- Step 3: Store the micro inverter properly. If you need to continue to use the inverter, ensure that the storage conditions meet the requirements.

9.5 Microinverter Disposal

Please dispose of the microinverters properly in accordance with local electrical equipment waste regulations, if the microinverter can not work properly. The microinverter can not be disposed of together with household waste.

X Technical Parameters

Model	M2-600W	M2-600W	M2-800W	M2-900W	M2-1000W
Input Data (DC)	M2-600G	M2-600G	M2-800G	M2-900G	M2-1000G
	M2-600WG	M2-600WG	M2-800WG	M2-900WG	M2-1000WG
Max. Input Voltage (Vdc)			60		
MPPT Voltage Range (Vdc)			16-60		
Start-up Voltage (Vdc)			22		
Max. Input Current Imax (A)	2*12	2*13	2*14	2*15	2*16
Max. Input Short-circuit Current Isc (A)	2*20	2*20	2*20	2*20	2*20
Number of MPPTs			2		
Output Data (AC)					
Nominal Output Power (Wp)	600	700	800	900	1000
Nominal/Max. Apparent Power (VA)	600/600	700/700	800/800	900/900	1000/1000
Max. Active Power (Wp)	600	700	800	900	1000
Nominal Output Current (A/V)	2.73/220 2.61/230 2.50/240	3.18/220 3.04/230 2.92/240	3.64/220 3.46/230 3.33/240	4.09/220 3.91/230 3.75/240	4.55/220 4.35/230 4.17/240
Nominal Voltage/Range (V)			220/230/240		
Nominal Frequency/Range (Hz)			50/60		
Power Factor			>0.99		
THDi			<3%		
Efficiency					
Peak Efficiency			96.5%		
Europe Efficiency	96.7%	96.7%	96.7%	96.5%	96.5%
MPPT Efficiency			99.9%		
Night Power Consumption (mW)			<50		
Protection Function					
Ground Fault Monitoring, Output Overvoltage Protection, Output Overcurrent Protection, Anti-islanding Protection, Surge Protection					
Features					
Active Power Regulation, Reactive Power Regulation, High Voltage Ride-through, Low Voltage Ride-through, Galvanically Isolated HF Transformer					
Others					
Dimensions (W*H*D, mm)			238*223*34		
Enclosure Material			ADC12 Aluminium Alloy		
Weight (kg)			2.9		
Operation Ambient Temperature (°C)			-40~65		
Type of Isolation			Galvanically Isolated HF Transformer		
Enclosure Rating			IP67		
Cooling			Natural Convection (No Fans)		
Altitude (m)			≤2000		
Grid Compliances			VDE-AR-N4105:2018-11		
Safety/EMC Compliances			IEC 62109-1:2010, EN 62109-2:2011, EN 62920:2017+A11:2020+A1:2021, EN IEC 61000-6-1:2019, EN IEC 61000-6-3:2021		
Protective Class			Class I		
DC Connector Type			MC4		
Communication			Built-in WiFi, Sub-1G		

Appendix

Installation drawing template

EPC:	Photovoltaic module type	Quantity:	table _____
User	Inverter Model:	Quantity:	_____
Row 1			
Row 2			
Row 3			
Row 4			
Row 5			
Row 6			
Row 7			
Row 8			
Row 9			
Row 10			

The mounting diagram shows the physical location of each microinverter on the mounting bracket. Each MOCO-WINI inverter has a serial number label, which is peeled off and glued to the corresponding position on the mounting diagram.

Hangzhou Hailiang New Energy Technology Co.,Ltd

Tel: +86-571-86959319

Email: service@mocowini.com

Address: HengSheng Building A,Bingjiang District,Hangzhou City,Zhejiang
Province,China.